2.2 Installation of This Software

Method of DC-7204v2 installation is described in this section.

Installation procedures

- ① Insert the CD-ROM containing the DC-7204v2 in the disc drive of the personal computer. Make sure that the DC-204R/204Ra is not connected to the personal computer.
- ② Execute [English] [Setup.exe] on the CD-ROM.



③ The User Account Control window may be displayed depending on the setting of OS. When it is displayed, click the [Yes] button.

User Account Control	×
Do you want to allow this app to make changes to your device?	
Č DC-7204v2	
Verified publisher: Tokyo Measuring Instruments Laboratory Co., Ltd. File origin: CD/DVD drive	
Show more details	
Yes No	

(4) If Microsoft .NET Framework 4.8, which is necessary for this software, is not installed on your personal computer, the installation screen for the Framework is displayed. Click the [Install] button. If Microsoft .NET Framework 4.8 is already installed, proceed to Step (6).

)C-7204√2	- InstallShield Wizard
3	C-7204v2 requires the following items to be installed on your computer. Click Install to egin installing these requirements.
Status	Requirement
Pending	Microsoft .NET Framework 4.8 Full
	Instal Cancel

(5) Installation of When Microsoft .NET Framework 4.8 is performed.



⑥ Start the installation of this software. Click the [Next >] button.

DC-7204v2 - InstallShield Wizard		×
ع ا	Welcome to the InstallShield Wizard for DC-7204v2	
	The InstallShield Wizard will install DC-7204v2 on your computer. To continue, dick Next.	
	< Back Next > Cancel	

⑦ [Choose Destination Location] is displayed.

If you want to change the destination, click the [Change...] button and choose the destination. If you do not change the destination, click the [Next >] button.

DC-7204v2	- InstallShield Wizard			×
Choose D Select fo	estination Location Ider where setup will install files.			X
	Install DC-7204v2 to: C:\Program Files (x86)\DC-7204v2			Change
InstallShield -		< Back	Next >	Cancel

(8) [Ready to Install the Program] is displayed. Click the [Install] button.

DC-7204v2 - InstallShield Wizard		×
Ready to Install the Program The wizard is ready to begin installation.		Z
Click Install to begin the installation.		
If you want to review or change any of your exit the wizard	installation settings, click	Back. Click Cancel to
Exit the wizh d.		
patallChiold		
15101131 11214		

(9) New window is opened, and [Start of the installation Wizard of the USB driver] is displayed. Click the [Next >] button to start the installation of the USB driver.



① The [Windows Security] dialog box may be displayed depending on the setting of OS. Click the [Install] button.



 [Completing the Device Driver Installation Wizard] is displayed. Click the [Finish] button to return to the installation of this software.

USB Driver for DC-104R/DC-204	4R installer			
	Completing the Device Driver Installation Wizard			
	The drivers were successfully in	stalled on this computer.		
	You can now connect your device to this computer. If your device came with instructions, please read them first.			
	Driver Name	Status		
	✓ Tokyo Measuring Instru	Ready to use		
	< Back	Finish Cancel		

InstallShield Wizard Complete] is displayed.Click the [Finish] button to complete the installation.



2.3 How to Connect to DC-204R/204Ra

Method of connecting the DC-204R/204Ra and the computer and method of confirming the connection are described in this section.

Connection procedures

Connecting to a computer

- ① Connect the DC-204R/204Ra to the computer by using a USB cable.
- ② When the DC-204R/204Ra is connected for the first time, the applicable device driver for the DC-204R/204Ra is automatically set.

X Device Setup		X Device Setup
Installing device Please wait while Setup installs necessary files on your system. This may take several minutes.	ightarrow	Installing DC-204R Please weit while Setup installs necessary files on your system. This may take several minutes.
Close		Close

Confirming of connection

- ① Open [Control Panel]-[Hardware and Sound]-[Device Manager].
- ② If you find [TML DC-104R/DC-204R] in the [TML_Meters], installation has been normally finished.



2.4 Uninstallation of This Software

This section explains how to uninstall the DC-7204v2.

Uninstallation procedures

- ① Open [Control Panel]-[Programs]-[Uninstall a program].
- ② Select [DC-7204v2].

→ ~ ↑ 🐷 > C	ontrol Panel > Programs > Programs and Features		~ C	Search Prog	grams and Featu
Control Panel Home	Uninstall or change a program				
View installed updates	To uninstall a program select it from the list and then	click Uninstall Change or Repair.			
Turn Windows features on or					
off	Organize 🔻 Uninstall				≣ -
	Name	Publisher	Installed On	Size	Version
	@DC-7204v2	Tokyo Measuring Instruments L	9/11/2024		2.0.0
	C Microsoft Edge	Microsoft Corporation	9/11/2024		128.0.2739.67
	Microsoft Edge WebView2 Runtime	Microsoft Corporation	9/11/2024		128.0.2739.67
	 Microsoft OneDrive 	Microsoft Corporation	9/11/2024	332 MB	24.166.0818.0003
	Microsoft Update Health Tools	Microsoft Corporation	2/13/2024	1.02 MB	5.72.0.0
	劇 Microsoft Visual C++ 2015-2022 Redistributable (x64)	Microsoft Corporation	1/10/2024	20.2 MB	14.32.31326.0
	👹 Microsoft Visual C++ 2015-2022 Redistributable (x86)	Microsoft Corporation	1/10/2024	17.6 MB	14.32.31326.0
	Nemote Desktop Connection	Microsoft Corporation	1/10/2024		
	VMware Tools	VMware, Inc.	1/4/2023	96.0 MB	12.1.0.20219665
	💐 Windows Driver Package - Tokyo Measuring Instrume	Tokyo Measuring Instruments L	9/11/2024		11/09/2018 4.1.0

③ Click [Uninstall].

Programs and Feature						- 0	>
$\leftarrow \rightarrow \checkmark \uparrow$	😨 > Control Panel > Prog	rams > Programs and Features		~ C	Search Prog	grams and Featu	P
Control Panel Home	Uninstall d	or change a program					
View installed updates	To uninstall a	program, select it from the list and then (click Uninstall, Change, or Repair.				
Turn Windows features off	on or Organize 🔻 🛛	Ininstall				≣ -	
	Name	^	Publisher	Installed On	Size	Version	
	@ DC-7204v2		Tokyo Measuring Instruments L	9/11/2024		2.0.0	
	© Microsoft Edg → Microsoft Cdg → Microsoft One → Microsoft Visu → Microsoft Visu → Microsoft Visu → Microsoft Visu → Remote Deskt → Windows Drive	e WebView2 Runtime Drive Hat Health Tools al C+- 2015-2022 Redistributable (x64) al C+- 2015-2022 Redistributable (x66) sp Connection r Package - Tokyo Measuring Instrume	Microsoft Corporation Microsoft Corporation Microsoft Corporation Microsoft Corporation Microsoft Corporation Microsoft Corporation Microsoft Corporation ViMeare. Inc. Tokyo Measuring Instruments L	9/11/2024 9/11/2024 9/11/2024 2/13/2024 1/10/2024 1/10/2024 1/10/2024 1/10/2024 1/4/2023 9/11/2024	332 MB 1.02 MB 20.2 MB 17.6 MB 96.0 MB	128.0.2739.67 128.0.2739.67 24.166.0818.0003 5.72.0.0 14.32.31326.0 14.32.31326.0 12.1.0.20219665 11/09/2018 4.1.0.	1
	Tok	yo Measuring Instruments Laborator.	Product version: 2.0.0 Help link: https://www.tr	Suppo ml.jp/e/	ort link: https:/	/www.tml.jp/e	

④ A confirmation dialog box is displayed. Click the [Yes] button to complete the uninstallation.

DC-7204v2 - InstallShield Wizard	\times
Do you want to completely remove the selected application and all of its features?	
Yes No	